

MultiMedia Card Still Camera & Digital Video Camera Compatibility List

AIPTEK DB-5300
Axia Eyeplate EPMEGA
BenQ DC 2410
BenQ DC E30
BenQ DC E43
BenQ DC2310
BenQ DC2410
BenQ DC3410
BenQ DC50
BenQ DC5330
BenQ DC-S30
BenQ DigiArt250
Besta DC-521
Besta Digi-eye S2
Canon 1D Mark 2 FAT32
Canon FV M1
Canon FV40
Canon FVM1
Canon FVM100
Canon IXUS I
Canon IXUS II
Canon IXY
Canon IXY Digital
Canon IXY Digital 30
Canon IXY Digital 30a
Canon IXY Digital 50
Canon IXY Digital L
Canon IXY DV3
Canon IXY L2
Canon IXY M2
Canon IXY30a
Canon IXYDV M3
Canon Optura20
Canon Optura200MC
Canon Pixus MP370
Canon PowerShot A400
Canon SD10 FAT32
Canon SD100 FAT32
Canon SD110 FAT32
Canon ZR45MC
Canon ZR85
CASIO Exilim EX-M2
CASIO Exilim EX-S2
CASIO Exilim EX-S20
CASIO Exilim EX-S20U FAT32
CASIO Exilim EX-S3
CASIO Exilim EX-Z3
CASIO Exilim EX-Z4
CASIO Exilim EX-Z4U FAT32
CASIO EX-M20

CASIO EXP600
CASIO EX-S100
CASIO EX-Z30
CASIO EX-Z4
CASIO EX-Z40
CASIO EX-Z50
CASIO EX-Z55
CASIO QV-R3
CASIO QV-R4
CASIO QV-R40
CASIO QV-R41
CASIO QV-R51
CASIO QV-R61
Concord 4360-Z
Contax LV
Contax SL300R
Contax T-VS
CREATIVE PC-CAM-880
Digilife DDV-S670
Digilife DG-L660
Digilife DG-M6
Digilife DG-Q4
Digilife DG-V4
Digilife DV-A4
Digimaster 210 Mouse
Digimaster Can walk DG-2000
Digimaster DIAMOND 660
Digimaster I-gic
Digimaster i-gic Super (4.0 mega)
Digimaster I-gic4 (4.0 mega)
Digimaster M3
Digimaster Mouse 410
Digimaster POW300
Digimaster POWER300
Digimaster Q-Shot (5.0 mega)
Digimaster S500
Digimaster Sex1 (4.0) Zoom Lens
Digimaster Skipper
DXG DVC305
DXG No type
EasyShare 6490
EPSON L-410
FASHION CAM DSC-321
FASHION CAM FASHION CAM
FASHION DXG660
FASHION FASHION CAM 4-IN-1
Fujitsu Siemens Options2
GATEWAY DC-M42
GATEWAY DC-T20
GATEWAY DC-T50
Genius D211
Hitachi DZ-MV380A
Hitachi DZ-MV580A
Hitachi Living Systems HDC-2V
Hitachi Living Systems HDC-
301SLIM

Hitachi Living Systems HDC-401

HP 635

HP PhotoSmart 435 FAT32

HP PhotoSmart 620

HP PhotoSmart 720

HP PhotoSmart 812

HP PhotoSmart 850

HP PhotoSmart 945

HP PhotoSmart M305

HP PhotoSmart M307

HP PhotoSmart M407

HP R607

HP R707

I-O DATA AVMC211

I-O DATA AVMC212

JVC D70K

JVC DVP9

JVC GD-D231U

JVC GR-D230

JVC GR-D230U

JVC GR-D90U

JVC GR-D93U

JVC GR-DV3000

JVC GR-DV800U

JVC GR-DV900

JVC GR-DV900U

JVC GR-DVL520

JVC GR-DVL820U

JVC GR-DVM90

JVC GR-DVM96U

JVC GR-DVP3E

JVC GR-DVP7

JVC GR-DVX600K

JVC GR-DX307

JVC GR-DX307U

JVC GR-DX95K

JVC GR-DX95U

JVC GR-DZ7U

JVC GZ-MC200U

JVC Mini D Camera Model 820

JVC ZR90

Kodak CX-4200

Kodak CX-4230

Kodak CX-6200

Kodak CX-6230 FAT32

Kodak CX-6330 FAT32

Kodak CX-7300

Kodak CX-7330

Kodak CX-7430

Kodak CX-7530

Kodak DCS Pro SLRn

Kodak DX-3215

Kodak DX-3700

Kodak DX410Z

Kodak DX-4330 FAT32

Kodak DX-4530 FAT32

Kodak DX500Z
Kodak DX-6340 FAT32
Kodak DX-6440 FAT32
Kodak DX-6490 FAT32
Kodak DX-7630
Kodak EasyShare LS633
Kodak EasyShare LS743
Kodak LS-420
Kodak LS-430
Kodak LS-443 FAT32
Kodak LS-630
Kodak LS-633
Kodak LS-6940
Kodak LS-743
Kodak LS-753
Kodak Pro back 14N
Kodak Tekxon
Kodak VQ3240
Kodak VQ3350
Konica Minolta DG-4W
Konica Minolta DiMAGE 7V2
Konica Minolta DiMAGE E223
Konica Minolta DiMAGE E323
Konica Minolta DiMAGE F100
Konica Minolta DiMAGE F200
Konica Minolta DiMAGE G400
Konica Minolta DiMAGE G500
Konica Minolta DiMAGE G530
Konica Minolta DiMAGE G600
Konica Minolta DiMAGE X20
Konica Minolta DiMAGE X31
Konica Minolta DiMAGE X50
Konica Minolta DiMAGE XG
Konica Minolta DiMAGE Xg1
Konica Minolta DiMAGE Xi
Konica Minolta DiMAGE XT
Konica Minolta DiMAGE Z10
Konica Minolta DiMAGE Z2
Konica Minolta DiMAGE Z20
Konica Minolta DiMAGE Z5
Konica Minolta KD-100Z
Konica Minolta KD-200Z
Konica Minolta KD-220Z
Konica Minolta KD-300Z
Konica Minolta KD-310Z
Konica Minolta KD-3300Z
Konica Minolta KD-420Z
Konica Minolta KD-500Z
Kyocera Contax SL300R
Kyocera Contax SL300RT
Kyocera Contax Tvs
Kyocera Finecam L3
Kyocera Finecam L3V FAT32
Kyocera Finecam L4
Kyocera Finecam L4V
Kyocera Finecam M400R

Kyocera Finecam M410R
Kyocera Finecam S3
Kyocera Finecam S3L FAT32
Kyocera Finecam S3R
Kyocera Finecam S3X
Kyocera Finecam S4 FAT32
Kyocera Finecam S5 FAT32
Kyocera Finecam S5R
Kyocera Finecam SL300R
Kyocera Finecam SL400R
Leica Digilux-1
Maginon DC3300
MEGXON C330
MEGXON C430
Microtek Take-it MV300
Microtek Take-it S3
MILEI DigiArt660
Minton Chipset: Sunplus 533
Mustek DV3500
Mustek DV4000
Mustek DV6M
Mustek MDC 5000
Mustek MDC 5500Z
NHJ CheEZ H2O
NHJ DZ320
NHJ DZ338
NHJ DZ438
NHJ D'zign DV-4
Nikon Coolpix 2200
Nikon Coolpix 3200
Nikon Coolpix 3700
Nikon Coolpix 4100
Nikon Coolpix 4200
Nikon Coolpix 4800
Nikon Coolpix 5200
Orite DC3110
Panasonic DMC-F1
Panasonic DMC-F1K
Panasonic DMC-F7
Panasonic DMC-FX1
Panasonic DMC-FX2
Panasonic DMC-FX5
Panasonic DMC-FZ10
Panasonic DMC-FZ2
Panasonic DMC-FZ20
Panasonic DMC-FZ3
Panasonic DMC-LC1
Panasonic DMC-LC20
Panasonic DMC-LC3
Panasonic DMC-LC33
Panasonic DMC-LC40
Panasonic DMC-LC43
Panasonic DMC-LC5
Panasonic DMC-LC50
Panasonic DMC-LC70
Panasonic DMC-LC70

Panasonic MX500
Panasonic NV-100K
Panasonic NV-50K
Panasonic NV-70K
Panasonic NV-C7
Panasonic NV-DS38
Panasonic NV-DS65
Panasonic NV-DS88K
Panasonic NV-GS100K
Panasonic NV-GS120K
Panasonic NV-GS400K
Panasonic NV-GS50K
Panasonic NV-GS55K
Panasonic NV-GS5K
Panasonic NV-GS70K
Panasonic NV-GX7K
Panasonic NV-MX1000
Panasonic NV-MX2000
Panasonic NV-MX3000
Panasonic NV-MX5000
Panasonic NV-MX7DEN
Panasonic optura 100MC
Panasonic PV-DC3000
Panasonic PV-DC3010
Panasonic PV-DV103
Panasonic PV-DV202
Panasonic PV-DV203
Panasonic PV-DV402
Panasonic PV-DV952
Panasonic PV-DV953
Panasonic PV-GS15
Panasonic PV-GS55
Panasonic PV-GS70
Panasonic PV-VM202
Panasonic SV-AS10--MP3
Panasonic SV-AU10U
Panasonic SV-AV10
Panasonic SV-AV100
Panasonic SV-AV30
Panasonic SV-AV50
Panasonic VDR-M30K
Panasonic VDR-M70K
Pentax Optio 33LF
Pentax Optio 33WR
Pentax Optio 43WR
Pentax Optio 550
Pentax Optio 555
Pentax Optio 750Z
Pentax Optio S
Pentax Optio S40
Pentax Optio S4i
Pentax Optio S50
Pentax Optio S5i
Pentax Optio SV
Pentax Optio X
Polaroid iON230

Polaroid PDC 3070
Praktica DV3
Premier DC2070
Premier DC2302
Premier DC3000
Premier DC3001
Premier DC3305
Premier DC3306
Premier DC4311
Premier DC5566
Premier DS-210
Premier DS4330
Premier DV-2000
Premier F4
Premier S2303
Premier S320
Premier X5
Pretec DV3300D
Primax Ezonic Discovery
Primax Ezonic EZ-S220
Primax Yoson
Ricoh Caplio 300G
Ricoh Caplio 400G Wide
Ricoh Caplio G2
Ricoh Caplio G3
Ricoh Caplio G4
Ricoh Caplio G4 wide
Ricoh Caplio GX
Ricoh Caplio RR30
Ricoh G4 Wide
Ricoh R300G
RITE VC-3300
RWC MobiDV-H10
Samsung D370
Samsung D4000
Samsung D401
Samsung Digimax 430
Samsung DigiMax-101
Samsung DigiMax-201
Samsung DigiMax-240
Samsung DigiMax-V3
Samsung DigiMax-V4
Samsung DigiMaX-V5
Samsung DigiMax-V50
Samsung Digital CAM VM-SCD303
Samsung U-CA5
Samsung V4000
Sanyo VPC-J2
Sanyo Xacti S3
Sanyo Xacti S4
Sharp VL-Z7
Sharp VL-Z75
Sharp VL-Z7U
Sharp VL-Z900
TCL TDC1818
Tekxon AX-480

Tekxon CX-432
Tekxon SX400
Tekxon TX MVP
Tekxon TX-1
Tekxon TX-2 (upto 256MB)
Toshiba PDR M700
Toshiba PDR T-10
Toshiba PDR T-15
Toshiba PDR T-20 FAT32
Toshiba PDR T-20 FAT32
Toshiba PDR-3310 FAT32
Toshiba PDR-4300
Toshiba PDR-5300
UMAX Power Cam 3660
Veo Smart Cam 2.1
VICTOR GR-DVP7
VICTOR GR-DVX600K
VICTOR GR-DX307
VICTOR GR-DX95K
Vivitar ViviCAM3330 FAT32
Vivitar ViviCAM3625 FAT32
Vivitar ViviCAM3765
Vivitar ViviCAM3825
Vivitar ViviCAM3935
VMAX Astra Pix610
VPC J2
WOLVERINE DC 400
Yakumo CX200